



DEAR VIEWER,

INSTRUCTIONS ON HOW TO GET EZEKIEL TV ON YOUR DSTV DECODER

1. Press MENU on your remote control.
2. Select ADVANCED OPTIONS
3. Select DISH INSTALLATION
4. PIN CODE 9949
5. Select HOME NETWORK – DSTV PAS 7 using your right arrow
6. Select NETWORK 2 – DSTV PAS 7
7. PRESS OK
 - a. FREQUENCY - 11170
 - b. SYMBOL RATE - 26652
 - c. FEC - 5/6
 - d. POLARISATION - VERTICAL
 - e. USE NIT - YES
 - f. Accept all displayed values and leave screen and Press OK
8. Go to NETWORK 3
 - a. FREQUENCY - 12682
 - b. SYMBOL RATE - 26657
 - c. FEC - 1/2
 - d. POLARISATION - HORIZONTAL
 - e. USE NIT - YES
 - f. Accept all displayed values and leave screen and Press OK
9. Go to MORE NETWORKS AND SELECT PAS/7/10 FROM DISABLED WITH RIGHT ARROW
10. Go to NETWORK 4
 - a. FREQUENCY - 11594
 - b. SYMBOL RATE - 27500
 - c. FEC - 5/6
 - d. POLARISATION - VERTICAL
 - e. USE NIT - YES
 - f. Accept all displayed values and leave screen and Press OK
11. RE-SCAN YOUR TV
12. USING YOUR REMOTE CONTROL – PRESS THE ‘TV’ BUTTON
13. SELECT DSTV – PAS7/10
14. PRESS OK
15. LOOK FOR EZEKI CHANNEL – THAT IS EZEKIEL TV

If you experience any problems do not hesitate to contact us on the above numbers.
